Date: December 2020



Plant Identification: Electric Rough Terrain Articulating Boom

Model(s)	HA20 LE PRO	Safe Working Load (kg)	350	Maximum Platform Drive Height (m)	18.8	Maximum Working Height (m)	20.8
----------	-------------	------------------------------	-----	--	------	----------------------------------	------

Contents

Introduction/Scope	1
Hazard Type Checklist	1
Hazard Control Measures	3
Product Safety	13

In accordance with the relevant Occupational Health and Safety Legislation for the region, this report serves as confirmation that each model type Haulotte product has undergone a risk assessment to the applicable market. The risk assessment investigates potential hazards associated with operation, maintenance, servicing, inspection, transportation and storage of the subject plant.

To assist, Haulotte provides Operators and Maintenance manuals for the product, which provides information regarding residual risks and correspondingly their control measures. Also, in accordance with the legislation, the information required to be supplied to the Purchaser, or User of the plant by the designer, manufacturer, supplier and importer can be found in the Manuals provided.

In addition to these manuals there may be industry safe use standards for the products that can be used to help with identifying potential hazards on the jobsite for ongoing servicing requirements (e.g. AS 2550.10).

Hazard Type Checklist

The table provides a summary of some potential hazards associated with the use of the plant. Haulotte evaluates each of these potential hazards during the risk assessment process in an effort to select specific control measures, (e.g. designs, guarding, warnings) that will reduce the likelihood that the operator, platform occupant(s), maintenance personnel or bystanders will be exposed to the hazard.

Many of these hazards can be identified in the SafeWork Australia Codes of Practice: Managing the Risks of Plant in the Workplace document, and AS/NZS 1418.10 Australian New Zealand Standard: Cranes, hoists and winches Part 10: Mobile elevating work platforms.

	entangled in moving parts, or objects in motion.					
	- Can anyone be crushed due to:					
	o material falling from plant					
	o uncontrolled motion or unexpected movement of plant					
	o the plant tipping or rolling over					
	o inadequate slowing or stopping devices of plant to control movement					
Crushing,	o support structure collapse					
Entanglement,	o being thrown from or under the plant					
Cutting, Severing,	o coming in contact with moving parts of the plant during testing, inspection,					
Stabbing,	operation, maintenance, cleaning or repair					
Puncturing, Shearing,	o being trapped between the plant and materials or fixed structures					
Friction,	-Cutting, stabbing & puncturing due to:					
Impact,	o contact with sharp or flying objects					
Trapping	o coming in contact with moving parts of the plant during testing, inspection,					
	operation, maintenance, cleaning or repair of the plant					
	o parts of plant or worksite material disintegrating or falling					
	o movement of plant					
	o can anyone's body parts be sheared between moving parts or surfaces of the plant					
	o can anyone be burnt due to contact with moving parts or surfaces of the plant					
	o can anyone be struck by moving objects due to uncontrolled or unexpected					
	movement of plant or work pieces (i.e. failure of the control system)					
	- Can anyone be injured due to:					
	o uneven or slippery work surfaces					
	o poor housekeeping in the vicinity of or in the plant					
	o obstacles being placed in the vicinity of the plant					
	o due to repetitive body movements					
	o constrained body posture or the need for excessive effort					
Ergonomic, Slipping,	o design inefficiency causing mental or psychological stress					
Tripping, Falling	o inadequate or poorly placed lighting of plant or workers IN THE WORKING AREA					
	o lack of failsafe measures against human error or human behaviour					
	o mismatch of plant with natural human limitations					
	o unhealthy posture or excessive efforts					
	o lack of personal fall protective equipment					
	o inadequate design/positioning of controls					
	- Can anyone come into contact with fluids under high pressure, due to plant failure or misuse					
	- Can anyone come into contact with objects at high temperatures, or objects which can cause					
High Pressure / High	fire or burning					
Temperature Fluids / Fire / Explosion	- Can anyone suffer illness due to exposure to high or low temperatures					
	- Can anyone be injured by explosion of gases, vapours, liquids, dusts or other substances					
	triggered by the operation of the plant or material handled by the plant					
Suffocation	- Can anyone be suffocated due to lack of oxygen, or atmospheric contamination					

Hazard Control Measures

HAULOTTE has implemented necessary control measures to minimise potential hazards to the operator, platform occupants, maintenance personnel and any bystanders (eg:- spotters on the ground). The control measures listed below is a summary of potential hazards associated with the plant itself and the necessary control measures implemented, as well as any other additional control methods required.

	T	1	ONTROL MEASURES	
NUMBER	HAZARD TYPE	RISK	RISK CONTROL METHOD	ADDITIONAL CONTROL METHOD REQUIRED
1	General OHS Hazards	Incident due to General Operation by a trained, or untrained, operator	 Comply with employer, job site and local council rules Read, understand and follow the instructions in the operator's and safety manuals supplied with the machine Use good safe work practices with a commonsense approach Only have trained/certified operators, directed by informed and knowledgeable supervision, running the machine 	 Address during company/site induction Manuals provided in a storage black box location on platform Quick Start reference guide provided describing critical operations
2	Worksite Hazards	Failure to conduct a jobsite risk assessment	 A complete jobsite specific risk assessment should be performed prior to using the plant. To assist with this effort, operators and maintenance manual identifies some of the common residual risks for the plant. 	 Every employer, user, and operator should review these residual risks and implement the necessary control measures to avoid them Users and employers should also research other supplemental information regarding the safe use of the plant, to support this effort (i.e. AS2550.10)
3	Crushing, Entanglement, Trapping, Impact, Cutting, Severing, Stabbing, Puncturing	Incident due to General Operation	 ActiveShield installed in place. Observe ASB light to ensure the Activeshield device is in working order Trapping and shearing points between moving parts which are within reach of persons on the work platform or standing adjacent to the plant at ground level are avoided by providing safe clearances or guarding, as applicable When the work platform of a plant needs to be raised for routine servicing purposes, the hydraulic system allows the extending structure to be held in the required position 	 Address during company/site induction Operator(s) to be aware of clothes and materials hanging near moving parts Tools and equipment may be kept in tool tray in basket

		HAZARD C	CONTROL MEASURES	
NUMBER	HAZARD TYPE	RISK	RISK CONTROL METHOD	ADDITIONAL CONTROL METHOD REQUIRED
		Objects falling from platform	 Kick rails / toe board around the bottom perimeter of platform is installed to avoid objects from falling Operator's manual warns personnel to keep clear of area beneath platform and to cordon off the area Machine is affixed with warning labels for collision with power lines 	• Tools and equipment to be kept in tool tray in basket. It may also be strapped down if required by site management.
3 (cont.)	Crushing, Collision / Striking	Sudden or unintended movements	 Striking due to sudden platform movements when driving is restricted with speed limiting Deadlock pedal interlock is provided to ensure against inadvertent operation by user An enable switch must be pressed before machine operation 	
		Operating in an area where obstacles, other people and plant may be present	 Beacon and motion alarm alert others in the area that the unit is in use Operator's manual contains instructions and guidelines for operating in these circumstances Drive movement not provided at ground controls 	• Site management must ensure platform and work area remains free of debris and clear from obstacles
		Underneath platform when platform is being lowered	 Plant is clearly labeled with warning decals due to the potential crushing hazard associated with the type plants Correct maintenance and operating procedures with safety instructions are provided in the Operator's manual 	
	Crushing	Machine falling off truck during transport	 Provision is made for both lifting and tie down Follow procedures within Operator's manual that is provided with the machine 	• Use glazier kit attachment to secure machine during transportation
		Lifting machine	 Designated lifting points are indicated by decals. Correct lifting procedure is provided in the Operator's manual. 	

		HAZ	ARD CONTROL MEASURES	
NUMBER	HAZARD TYPE	RISK	RISK CONTROL METHOD	ADDITIONAL CONTROL METHOD REQUIRED
	Entanglement, friction, cutting	Failure of Engine components	 Engine components are enclosed under covers Fan blades are covered Warning decals are affixed. Operators are not subjected to friction as there are no high speed exposed components Guards provided is of a fixed permanent nature and can be removed with tools 	 Maintenance to be carried out by qualified personnel Slew movement provided at ground controls for emergency operation Trained and competent ground personnel required to use ground controls
3 (cont.)	Entanglement, shearing	Failure of engine components	 Crushing hazard decals are clearly displayed on the plant. Warnings are placed in operator's manual to prevent entanglement. Decals fitted to boom arms and linkages. 	• JSA, Training and Supervision to be provided by site management.
	Friction	Mechanical Failure of Wheels	 Operators are not subjected by the plant to friction, as there are no high speed exposed components Mechanical failure due to friction is reduced with self-lubricating bushes and wear pads Locations of lubrication points are shown in the manual. Also a lubrication schedule is provided along with grease types to be used 	
	Cutting, Stabbing, Puncturing	General Operation	 Controls and other contact surfaces have no sharp edges. Controls are ergonomically designed. 	 Bystanders must stay clear when plant is operational.
4	Ergonomic, Slip/Trip/Fall	Loss of braking while travelling	 Brakes on the plant automatically engage when the power to them has stopped or failed. Brakes are capable of holding the plant on approved slopes. The plant stopping distance at maximum speed meets the design requirements. Control positions on the plant are located and designed to allow excellent visibility and to allow slow, deliberate movements to prevent contact with adjacent objects. When the platform of the plant is elevated, the drive speed is reduced. Proportional drive is provided 	

		HAZA	RD CONTROL MEASURES		
NUMBER	HAZARD TYPE	RISK	RISK CONTROL METHOD	ADDITIONAL CONTROL METHOD REQUIRED	
4 (cont.)	Ergonomic, Slip/Trip/Fall	t.) Slip/Trip/Fall	Loss of braking while travelling (cont.)	 Operators are protected from falling from platform with a solid peripheral railing around the entire platform Harness attachment points are provided and labeled on the platform RED emergency buttons are positioned at all control stations Interlocks are designed in to prevent unintended movement 	 Site management to ensure occupants in platform wear a fall arrest harness, with lanyard Use a harness adjusted to your size that has been inspected by a competent person.
	(cont.)	Poor visibility	 ActiveLighting system installed to ensure adequate lighting during darker environments 		
		Unintended platform movement	• Extending system is designed and constructed to prevent any inadvertent movements of the extending structure.		
5	High Pressure, High Temperature Fluids / Fire / Explosion	High Pressure fluid jets resulting puncturing the skin or eyes	 Hydraulic hoses used have a bursting pressure well over working pressure Engine hood in place to isolate from high temperature fluid danger / fire Relief valves are used to prevent over pressurizing the hydraulic system Engine exhaust is directed away from the control positions and from all electrical wirings Guards are provided at control stations protecting the persons, or standing adjacent to the plant at ground level, against thermal and mechanical hazards High temperature components such as engine and pump are positioned out of arms reach and in enclosures Filling points for flammable fluids are positioned to minimise the risk of fire from spillage on hot parts 	 Fire extinguishers to be provided following job assessment. JSA, training and supervision must be provided by site management. 	
6	Suffocation	Inhalation of exhaust gases	 Exhaust gas is directed away from the operator The size of the machine prevents operation in confined spaces, therefore exhaust gas inhalation is not considered to pose a problem. The design of the platform is that of open air 	• Use no emission / electric mode of operation to reduce fumes	

		1		ADDITIONAL CONTROL
NUMBER	HAZARD TYPE	RISK	RISK CONTROL METHOD	METHOD REQUIRED
		Electric Shock due to working too close to power lines	 Machine is clearly marked with electrical warning decals to reduce the risk Operator's manual states that the machine is not insulated Safe operating procedures and minimum approach distances are placed in the manual Decal - Minimum safety distance from the energized/power lines is fitted to the machine 	• JSA, training and supervision must be provided by site management to ensure safe working clearances from the electric field are assessed. Consider boom deflection in the assessment of the safe working distance.
7	Electrical	Shock from electrical system	 Machine is fitted with 240V outlets which have an earth leakage circuit breaker and wiring, as applicable Cables are insulated and secured to plant. These cables have protective rubber boots over connection points to prevent contact shorting during maintenance Inspection and maintenance procedures are placed in the operating manual 	
		Short circuit due to loose wire	 Connectors used are either insulated crimp lugs, locking plastic plugs, or permanent type clamps Wiring is routed to prevent chaffing Plants are fitted with the control system which uses malfunction/error signals to assist in faultfinding Fault codes are explained in the operating manual 	Conduct inspection as scheduled
		Short circuit due to water bridging	 Wiring looms of control boxes are covered with water resistant covers Electric components are tested for water damage Control cards for functions and flow control are encased in epoxy resin to prevent water damage Inspection and maintenance procedures are placed in the Operator's manual 	

		HAZA	RD CONTROL MEASURES	
NUMBER	HAZARD TYPE	RISK	RISK CONTROL METHOD	ADDITIONAL CONTROL METHOD REQUIRED
7 (cont.)	Electrical (cont.)	Battery under/over charging	 Battery is automatically charged while engine is running and, as it is only being trickle charged Safe charging procedures are placed in the operator's manual 	 As required, charge battery in a well ventilated area at a safe distance from any ignition source
	Unauthorised use / access to machine Overloading the platform	 Plant is equipped with a key switch to prevent unauthorised use Additionally only one control station can be operated at any given time Maximum safe working load and number of people is clearly marked on the machine 	• Do not overload platform or carry material which increases wind surface area.	
		Excessive manual side force	• Maximum allowable manual side force is marked on machine	
8	Stability	Tip Over	 All machines have undergone detailed stability analysis. These calculations take into consideration the machines expected operating configuration, envelope, and approved operating conditions (i.e. slope) Stability analysis takes into consideration a number of foreseeable forces including gravitational (based on rated capacity), dynamic, wind, and manual forces. Stability analysis not only evaluates 	
			 the plant's static condition, but also potential effects of dynamic conditions (i.e. braking, and depressions). Stability analysis is verified by physically testing the static and dynamic stability of the design. 	

NUMBER	HAZARD TYPE	RISK	RISK CONTROL METHOD	ADDITIONAL CONTROL METHOD REQUIRED
8 (cont.)	Stability	Side force slope	 Interlocks prevent plant operation on excessive slope Tilt switch provides an audible and visual alarm when plant is put in an out of level condition Machine is counterweighted to meet requirements A permanent type specification plate is permanently attached to the plant which shows SWL, max slope, max side force and wind speed Operator's manual states that the machine is not to be driven and the platform must not be elevated on sloping, uneven or soft ground. Warning decals are placed on plant, and safe operating procedures are placed in the operator's manual 	 Site management to ensure occupants in platform wear a fall arrest harness, with lanyard and follow local council regulations Site management to ensure operators are trained in machine operation and plant is operated within specified limits
	(cont.)	Travelling too fast	 Plant is equipped with a chassis inclination device, which sounds an alarm when the terrain slope is approaching the allowable limits. Travel speed is limited when elevated. Interlocks prevent plant operation on excessive slope. Braking is designed to hold the plant on its maximum rated grade. Plant is tested for dynamic stability in various conditions as per requirement. Warning decals are placed on plant, and safe operation and transportation procedures are placed in the operator's manual. A permanent type specification plate is stamped with design limits Direction arrows (green/red) fitted to chassis and control position 	 Site management to ensure occupants in platform wear a fall arrest harness, with lanyard and follow local council regulations Operate machine in accordance with load, slope and wind limits
		Driving too fast when elevated	• Control system limits the travel speed when elevated	
		Check or relief valve failure	 An emergency overriding system is installed to allow emergency retrieval Inspection and maintenance procedures are placed in the manuals 	• Site management to ensure a ground crew member is trained in emergency retrieval of plant.

		HA		
NUMBER	HAZARD TYPE	RISK	RISK CONTROL METHOD	ADDITIONAL CONTROL METHOD REQUIRED
8 (cont.)	Stability (cont.)	Incorrect equipment adjustment	 Test points are provided for checking of pressure settings e.g. drive and lift relief Adjustment points require tools to change Correct adjusting procedures are placed in the manual Hydraulic (and other) specifications are listed to enable adjustment 	
	Unintended platform movement	 Deadman pedal is fitted and dual input is required by operator When power to the controls stop or fails, this system automatically locks the work platforms movements, in any position 	 Training and supervision must be provided by site management 	
		Excessive pressure build-up	 Relief valves are used to prevent over pressurizing the hydraulic system. Holding valves prevent unsafe descent in the advent of failure. Correct pressures listed in the service manual Hydraulic hoses used have a bursting pressure well in excess of the working pressure Inspection and maintenance procedures are placed in the Operator's manual 	
9	Hydraulic	Hydraulic Overloading the structure and drive system.	• Pressure limiting devices are provided to protect the extending structure, and drive system, to prevent structural damage	• Do not overload platform
		Mechanical Pump, motor, control valve or interlock failure	 In the advent of pump or motor failure, an emergency overriding system is installed on the machine Holding valves on cylinders prevent inadvertent movement Holding valves are installed to prevent decent due to hydraulic failure. Inspection and maintenance procedures and daily inspection list are placed in the operator's manual 	 Inspection, cleaning, maintenance and repair must be conducted when plant is stationary Site management to ensure a ground crew member is trained in emergency retrieval of machine

NUMBER	HAZARD TYPE	RISK	RISK CONTROL METHOD	ADDITIONAL CONTROL METHOD REQUIRED
			 The machines have undergone detailed structural analysis These calculations take into consideration the machine's expected operating configuration, envelope, and approved conditions (i.e. slope) 	 Conduct 10 yearly major inspections to check for structural integrity of the machine
		Failure of any structure	• Structural analysis takes into consideration a number of foreseeable forces including gravitational (based on rated capacity), dynamic, wind and manual forces	
			• Structural analysis is verified by physically testing the structural soundness through both static and dynamic loading	
		Fatigue	 The machine has been cyclic tested beyond its rated design life cycle against fatigue Maintenance schedule including annual inspections provided in the manuals 	
10	Structural	Wear and corrosion	 Corrosive surfaces are painted, components subject to wear have provisions to minimize wear by using sacrificial components or lubrication e.g. wear pads, self-lubricating pins Lubrication points and a schedule for maintenance are provided in the manual 	 Conduct pre-operational inspections and periodic inspections as scheduled
		General overload	 A relief valve is used to prevent excessive loads being lifted by the platform Tools are required to alter pressure settings Test points are provided for checking of pressures Warning decals on machine show safe working loads Safe operating procedures are placed in manual 	• Do not overload the platform
		Overloading Platform	• The machine is equipped with a load- sensing system, which protects the plant and operator from reaching a point where the platform can be operated when the platform has been overloaded	 Do not overload the platform at elevated heights
		Tip Over	• To help avoid overturning of the plant the structure for the plant is equipped with non-mechanical limiting devices (i.e. limit switches) to limit the operation	

HAZARD CONTROL MEASURES						
NUMBER	HAZARD TYPE	RISK	RISK CONTROL METHOD	ADDITIONAL CONTROL METHOD REQUIRED		
11	Slip / Trip / Fall	General Operation	 Operators are protected from falling from platform with a solid peripheral railing around the entire platform. Harness attachment points are provided on the platform. RED emergency stop buttons are positioned at controls stations. 	• Site management to ensure occupants in platform wear a fall arrest harness, with lanyard and energy absorber in accordance with governmental regulations.		
		Within the platform	 Operators manual says to keep platform floor free of debris. Interlocks are in place to prevent inadvertent movements. An enable button must be pressed before operation. Solid handrail is provided to hold on to while operating the platform controls. 	• Site management to ensure occupants in platform wear a fall arrest harness, with lanyard and energy absorber in accordance with governmental regulations.		
	Operator	Loss of Control	 Controls are designed to operate with one hand and are either of joystick, toggle or button type. Non-assisted controls are minimized using electrical actuation. Where controls are mechanical in nature operating effort is reduced as far as practicable. Controls return to neutral upon release and movement will only occur when physically actuated. 	• Site management to ensure platform remains in clean, free of debris and safe condition.		
		Maintenance Error	 Components which require regular maintenance such as filters are placed in an easily accessed area The machine features hinged compartments which house battery, motor, valve bank etc., away from the chassis for easy access 	Only trained, qualified personnel must do maintenance work		
		Unclear Controls	 Control box face plates use pictures for functions, and switches, which control 'direction', operate in that direction Machines are field tested for controllability and ease of use Handrails are provided around control station for support during motion Warning decals are used to warn of incorrect operating procedures 	• Replace control box faceplate label(s) if damaged		

Noise Neighb distur		 Use no emission / electric mode of operation to reduce engine noise levels
------------------------	--	--

Product Safety

The information provided in this document is only a small example of the activities which have been undertaken by Haulotte to ensure the safety of the plants.

These include:

- Performing computer simulation/modeling of product and internal design calculations.
- Independent design review by an independent engineer to local design requirements is completed in Australia.
- Cycle testing of components to ensure fatigue life is adequate for a 10 year life is completed.
- Extensive field testing of prototype units to ensure faults and hazards are identified.

Occupational Health & Safety Legislation

The below legislation has been used to produce this document.

ACT, NSW, QLD: Work Health and Safety Act 2011

- NT: Work Health and Safety (National Uniform Legislation) Act 2011
- SA, TAS: Work Health and Safety Act 2012
- VIC: Occupational Health and Safety Act 2004

WA: Occupational Safety and Health Act 1984